

FAQ

NR: 025

SOFTWARE: 3D-VIZ CONTROL

FEHLER

Error message: Could not connect to EPOS Controller

Please be sure:

1. The turntable is ON.
2. The turntable is connected to the computer with the USB-cable.
3. Please check the USB-cable if its damaged. If yes, please try another USB cable.