

FAQ

NR: 030

SOFTWARE: 3D-VIZ CONTROL

HANDLING

What means „Go to Position“?

By entering a value you can move to this position directly.