

# FAQ

NR: 031

SOFTWARE: 3D-VIZ CONTROL

HANDLING

**I press the camera icon, but the camera does not release.**

check it out

1 Whether the camera is turned on.

2 The camera is not in sleep mode.

3 Check all cables in good working order.

4 The autofocus is off.

5 Go to the menu bar and select from „shutter“ shutter speed:

0.1; 0.2; 0.3; 0.4; 0.5; seconds.