

# FAQ

NR: 040

HARDWARE: KAMERA

## Why does my camera not trip?

Make sure that the camera is set to manual focus.  
To trip the camera 3D-VIZ CONTROL must be on.  
Or exchange the connecting cable.