

# FAQ

NR: 041

HARDWARE: CAMERA

**My camera is connected and set to manual focus. When I start the turn the camera first trips at position 2?**

Your camera is in Sleep Mode. Set the Sleep Mode to „OFF“.