

FAQ

NR: 042

HARDWARE: CAMERA

The photograph process runs but I get only black images.

If you photograph on a CF-card, this is too slow.
Adjust the turntable speed down.